

AudioLuxe Experience

QUICK START GUIDE

GUIA DE INICIO RAPIDO

GUIDE DE DEMARRAGE RAPIDE

La-Z-boy®

SOUND BY *Klipsch*

We've got your back!

Everything you need to know about your La-Z-Boy® AudioLuxe system is right here. Our simple quick start guide will ensure you get the most from every feature. Download or bookmark this guide so you can revisit as needed.

Then relax, unwind, and enjoy.

Need more help? Contact your local La-Z-Boy® dealer or call La-Z-Boy® Comfort Care at 855-802-6636 for assistance.

IMPORTANT

Read the safety and other instructions before using your Power Recliner with Headrest, Power Recliner with Headrest and Lumbar, Power Sofa with Headrest and Power Sofa with Headrest and Lumbar furniture. Keep this manual for future reference.

TABLE OF CONTENTS

Getting To Know AudioLuxe 4-6

Connecting a Bluetooth® Device 7-8

Auracast™ Audio Sharing 9

Audio Transmitter Pairing..... 10-11

Disclaimer: The information and products featured in this manual may be somewhat different from the product you purchased. La-Z-Boy reserves the right to make substitutions that are equal in quality and performance.

GETTING TO KNOW AUDIOLUXE

Use the illustrations below to identify the controls, indicators, and accessories of your AudioLuxe system.

AUDIO CONTROL PANEL

1. Volume Wheel adjusts the audio volume.
2. Source LED indicates Bluetooth® source status.
3. Auracast™ LED indicates Auracast™ status.
4. Source Button used for Bluetooth® pairing and source selection.
5. Auracast™ Button starts or joins Auracast™ audio sharing.




SAVE THESE INSTRUCTIONS

LED STATUS REFERENCE

LED	INDICATOR	STATUS
Source LED (Blue/White)	 Slow Blinking Blue	Bluetooth® Not Connected
	 Quick Blinking Blue	Bluetooth® Pairing Mode
	 Solid Blue	Bluetooth® Connected
	 Slow Blinking White	Audio Transmitter Not Connected Mode
	 Quick Blinking White	Audio Transmitter Pairing Mode
	 Solid White	Audio Transmitter Connected Mode
	 Off	No Bluetooth® Connection
Auracast™ LED (White)	 Blinking White	Auracast™ Pairing Mode
	 Solid White	Auracast™ Connected
	 Off	No Auracast™ Connection


AUDIO TRANSMITTER

- 1. USB-C used for firmware updates.
- 2. USB-A Sound Bar Connection connects to Klipsch Flexus Core Sound Bar.
- 3. Status LED indicates wireless connection status.
- 4. Wireless Pairing Button used for pairing.



GETTING TO KNOW AUDIOLUXE (CON'T)

SOUND BAR PORTS AND BUTTONS



1. AC Power Cord
2. IR infrared remote control extender.
3. HDMI eARC recommended TV connection method.
4. Optical connection to TV.
5. Sub Out for adding a physical subwoofer to the sound bar.
6. USB-C only for firmware updates using a USB-C thumb drive.
7. Flexus Transmitter Port for Audio Transmitter when used with the La-Z-Boy furniture.
8. Pair Button not used with the La-Z-Boy furniture.

SOUND BAR TOUCH CONTROLS



1. Power turns the sound bar on or off.
2. Source cycles through available inputs.
3. Volume Up increases the volume.
4. Volume Down decreases the volume.

CONNECT A BLUETOOTH® DEVICE

LED Key

○ Off



Slow Blinking White



Slow Blinking Blue



Quick Blinking White



Quick Blinking Blue




Solid White



Solid Blue

Verify Bluetooth® Mode


When the system powers on, the **Source** LED should flash blue, indicating Bluetooth® mode is available.



Enter Pairing Mode

1. Long press the **Source** button for approximately **1 second**.
2. Release the button.
3. The **Source** LED will begin quick blinking blue.
4. The pairing tone will play.

The system is now ready to pair with a Bluetooth® device.




CONNECT A BLUETOOTH® DEVICE (CON'T)

Connect Your Device

1. Open the Bluetooth® settings on your phone, tablet, computer, or other source device.
2. Select **La-Z-Boy (XX:XX)** from the list of available devices.
3. Wait for the connection to complete.
4. The paired tone will play.

The **Source** LED will remain solid blue when the Bluetooth® connection is established.



AURACAST™ AUDIO SHARING

Auracast™ allows one seat to share audio with other compatible seating systems.


TO START SHARING AUDIO

On the Audio Source Seat

1. Connect a Bluetooth® device and begin audio playback. (See pages 7-8)
2. Confirm the **Source** LED is solid blue.
3. Short press the **Auracast™** button once (approximately **0.5 seconds**).

Result:

- An Auracast™ confirmation tone plays.
- The **Auracast™** LED turns solid white.
- The **Source** LED remains solid blue.



RECEIVE SHARED AUDIO


On Additional Seats

1. Ensure the seat is not currently playing audio.
2. Short press the **Auracast™** button (approximately **0.5 seconds**).

Result:

- An Auracast™ confirmation tone plays.
- The **Auracast™** LED turns solid white.
- The **Source** LED remains off.

The seat is now receiving shared audio from the broadcast source.



Add More Seats


Repeat the receiving procedure on each additional seating system you want to join the audio group.

AUDIO TRANSMITTER PAIRING

PAIR WITH KLIPSCH FLEXUS CORE 200 SOUND BAR


Install the Audio Transmitter

Plug the audio transmitter into the **Flexus Transmitter Port** on the back of the sound bar.



Select Wireless Audio Mode


1. Short press the **Source** button on the Audio Control Panel (approximately **0.5 seconds**) until the **Source** LED is slow blinking white.



AUDIO TRANSMITTER PAIRING (CON'T)


Select Wireless Audio Mode (con't)

2. Long press and release the **Source** button on the Audio Control Panel (approximately **1 second**) until the **Source** LED is quick blinking white.
3. The pairing tone will play.



Repeat the receiving procedure on each additional seat to be connected to the transmitter.

4. Long press (approximately **1 second**) the Wireless Pairing Button on the Audio Transmitter until the LED quickly blinks blue. Release the button.



Result:

- The system will play the 5G paired tone.
- The **Source** LED turns solid white.
- Seating system and transmitter are connected and ready for use.

